

DRILLING TEMPLATE



This pack contains:

2 x Metal fixing pins
1 x Syringe of adhesive

Tools required:

Drill
6mm Drill Bit



Installation time:

15 minutes



Hidden Fixings Fitting Instructions

We recommend you read through these instructions before you start installing your sign.

- 1 Take your paper drilling template and tape it into position on your wall, making sure you're not drilling into mortar.
- 2 Using a 6mm drill bit, drill through the two fixing holes on the paper into the wall.
- 3 Next turn your sign over in preparation for the fixing pins.
- 4 Take your tube of adhesive and push down on the lid so it breaks the seal.

IMPORTANT: This adhesive sets quickly! Only break the seal when you're ready to install.

- 5 Squeeze some of the adhesive into the holes in the back of your sign and push the fixing pins in, making sure they are straight. Hold them for a few seconds until the adhesive starts to set.
- 6 You can then align the pins with your drill holes and push your sign into position.

If you'd like your sign to be fixed permanently, then squeeze some of the adhesive into the drill holes in your wall before aligning the sign.



UK SIGN
SHOP