

Button Fixings

Fitting Instructions

We recommend you read through these instructions before you start installing your sign.

- 1 Take your paper drilling template and tape it into position on your wall making sure it's level and that you're not drilling into any mortar.
- 2 Using a 6mm drill bit, drill through the two fixing holes on the paper into the wall.
- 3 Insert your wall plugs into both holes and screw the green button fixings into position with the flat face against the wall.
- 4 Next take your sign and line up the fixings on the back with the fixings on the wall and push down firmly. You should hear a click when it's in position.

**That's it, you're all finished!
Why not have a nice cuppa tea to celebrate a job well done.**

DRILLING TEMPLATE

Tools required:

Drill
6mm Drill Bit
Screwdriver

Installation time:

15 minutes



**UK SIGN
SHOP**